



Pecan Pie Wax Melts Recipe

Recipe makes 12 wax melts.

Here's What You Need:
Ingredients

[Joy Wax](#)

[Pillar of Bliss Candle Wax](#)

[Granny's Pecan Pie Fragrance Oil](#)

[Spectrum Liquid Candle Dye- Brown 1oz.](#)

[Spectrum Liquid Candle Dye- Yellow 1oz.](#)

[Spectrum Liquid Candle Dye- Black 1oz.](#)

[THERMOMETER](#)

[Silicone Mold- 12 Mini Muffins](#)

Other Ingredients & Equipment You'll Need:

Mixing Bowls

Mixing Spoon

Scale

Pot (for double boiler)

Wax Paper

Pecan Mold (www.flexiblemolds.com)



Here's How It's Done : Directions

Step 1: Prepare the Bases: Use a double boiler to melt 325 grams of Pillar of Bliss Candle Wax. Once melted, add 3 drops of the yellow liquid candle dye and 4 drops brown candle dye. Then, add 32 grams of Granny's Pecan Pie Fragrance Oil. Stir to incorporate the ingredients. Pour the wax into each cavity of the silicone mini muffin mold. Once setup, remove them from the mold and set them on a piece of wax paper. We will come back to it.

Step 2: Prepare the pecan embeds. Melt 50 grams of the Pillar of Bliss Candle Wax using a double boiler. Then, use toothpicks to add a small amount of both brown and yellow candle dye. Finally, add 5 grams of the Granny's Pecan Pie Fragrance Oil. Use a spoon to blend the ingredients together. Pour the wax into the pecan mold.

Step 3: Once the pecans have setup, remove them from the mold. Remelt your candle wax and once again, fill the pecan mold. When they have setup remove them from the mold. You will need a total of 12 pecans for this recipe.

Step 4: Now, prepare the chocolate drizzle. Weigh out 20 grams of Joy Wax. Melt the wax and add 2 grams of Granny's Pecan Pie Fragrance Oil. Then, using toothpicks, add both black and brown liquid candle dye. Stir. Use a spoon to drizzle the melted wax over the bases you prepared in the first step.

Step 4: Next, prepare the whipped wax. Using a double boiler, melt 120 grams of Joy Wax. Then, add 12 grams of Granny's Pecan Pie Fragrance Oil. Stir to incorporate the scent.

Step 5: Begin whipping your Joy Wax. You want to begin whipping the wax when it is just starting to setup. Once you have a whipped topping consistency, place a dollop on top of each cupcake base.

Step 6: Place a pecan embed on top of each wax melt.

Your Pecan Pie Wax Melts are ready to use once they have cured! Simply place a wax tart in your burner and allow the pecan aroma to fill the air!

Natures Garden is not responsible for the performance of any of the recipes provided on our website. Testing is your responsibility. If you plan to resell any recipes we provide, it is your responsibility to adhere to all FDA regulations if applicable. If there are ingredients listed in a recipe that Natures Garden does not sell, we cannot offer any advice on where to purchase those ingredients. We also do not offer any advice on formulating or altering recipes.