



Strawberries and Cream Wax Melts Recipe

Recipe makes 6 strawberry wax melts.

Here's What You Need:
Ingredients

[Joy Wax- 1 SLAB](#)
[Pillar of Bliss Wax](#)
[Color Block – Red](#)
[Strawberries and Cream Fragrance Oil](#)
[POURING POT](#)
[THERMOMETER](#)

Other Ingredients & Equipment You'll Need:
Scale
Mixing Spoons
Mixing Bowl
Pot (For Double Boiler)
Vanilla Wafers Soap and Candle Mold
(flexiblemolds.com)



Here's How It's Done : Directions

Step 1: First, we will prepare the vanilla wafers portion of the melt. So, weigh out 90 grams of the Pillar of Bliss Candle Wax.

Step 2: Next, melt the wax using the double boiler method. Once melted, add just a pinch of your red color block and stir to fully mix the color throughout the wax. You will need very little, add a tiny piece and then check your color. You can easily figure out if it is the color you are looking for. Use a spoon to place a drop of the colored wax onto a white napkin or paper plate. If you find it to be too light you can add more color block.

Step 3: Now, add 9 grams of Strawberries and Cream Fragrance Oil to the melted wax. Again, mix to incorporate the strawberry scent.

Step 4: Pour your strawberry scented wax into each cavity of the vanilla wafers mold. Allow these wafers to setup. Once setup, remove the wafers from the mold.

Step 5: Prepare your Joy Wax. Again, melt the wax using a double boiler. Melt 90 grams of Natures Garden Joy Wax. This portion will remain uncolored. However, we will be adding the Strawberries and Cream Fragrance Oil. Add 9 grams of the strawberry fragrance oil and stir.

Step 6: Transfer the uncolored wax to a small mixing bowl. You can keep it in the pouring pot, however, transferring the candle wax will help the wax to setup quicker and make it easier to whip.

Step 7: As the Joy Wax begins to thicken, whip the candle wax using a spoon or rubber spatula. Continue whipping until you have a whipped cream consistency.

Step 8: Finally, begin adding the cookie filling. Add a bit of the wax frosting to 6 of the vanilla wafers. Then, quickly place another wafer on top to create a cookie sandwich.

Step 9: Once you have created the cookie sandwiches, allow them to finish setting up. Once you have allowed your strawberry wax melts to cure for a couple of days they are ready to use. Simply place a wax melt in your wax burner and enjoy!

Natures Garden is not responsible for the performance of any of the recipes provided on our website. Testing is your responsibility. If you plan to resell any recipes we provide, it is your responsibility to adhere to all FDA regulations if applicable. If there are ingredients listed in a recipe that Natures Garden does not sell, we cannot offer any advice on where to purchase those ingredients. We also do not offer any advice on formulating or altering recipes.